



1. Disconnect your Negative (Black) battery terminal
2. Safely raise the vehicle on jack stands, a ramp or lift, allowing access to the H Pipe or X Pipe (middle section of exhaust)
3. Unplug the harness on each of the rear oxygen sensors, located after the catalytic converters on your H Pipe or X Pipe.
4. Plug the O2 Sensor MIL Eliminators in-line, between the wiring harness and the Oxygen Sensor harness. It will only fit one direction

Important Note: Depending on your model year Mustang, you may need to trim off the outer tabs on the harness for them to fit correctly. This can be done with a file, knife or cutters.



5. Lower your vehicle and reconnect the battery terminal

Visit WWW.OBDINNOVATIONS.COM for more resources including:

- Driver and Software downloads
- Setup Guides for Car Diagnostic Software
- Technical Info, Installation guides and more